


ROMSTAR™ INC.

ARKANOID™

Instruction Manual



Romstar, Inc.
3043 Kashiwa Street, Torrance, CA 90505
Phone (213) 539-2744 Fax (213) 539-3626 Telex 182426

Licensed From TAITO™
All Rights Reserved ©1986

ARKANOID WIRE HARNESS (G)

WIRE COLOR	PARTS SIDE			SOLDER SIDE COLOR	WIRE
Black	Ground	1	A	Ground	Black
Red	Video Red	2	B	Video Ground	Brown
Green	Video Green	3	C	Video Blue	Blue
Gray	Video Sync (Neg)	4	D	N/A	
White	Speaker (+)	5	E	Speaker (-)	Black
	Post	6	F	Post	
	N/A	7	H	N/A	
Pink	Coin Switch	8	J	N/A	
Yellow	Coin Meter	9	K	N/A	
	N/A	10	L	N/A	
Tan	Serv Switch	11	M	Tilt Switch	Red
Brown	1P Select	12	N	2P Select	Gray
	N/A	13	P	N/A	
	N/A	14	R	N/A	
Green	1P Right	15	S	2P Right	Green
Blue	1P Left	16	T	2P Left	Blue
	N/A	17	U	N/A	
	N/A	18	V	N/A	
	N/A	19	W	N/A	
	N/A	20	X	N/A	
Red	1P Fire	21	Y	2P Fire	Red
	N/A	22	Z	N/A	

ARKANOID WIRE HARNESS (H)

WIRE COLOR	CONNECTION	
Black	Ground	1
Black	Ground	2
Black	Ground	3
Black	Ground	4
Red	+5VDC	5
Red	+5VDC	6
Red	+5VDC	7
	N/A	8
Yellow	+12VDC	9
	Post	10
	N/A	11
	N/A	12

NOTE :

Double the red wire from pin 7

SETTING OF DIP SWITCH

SETTING		POSITION	1	2	3	4	5	6	7	8
PLAY PRICING	* 1 Coin 1 Play	OFF	OFF							
	Coin 2 Plays	ON								
	2 Coins 1 Play	OFF	ON							
	1 Coin 6 Plays	ON								
NUMBER OF PLAYER	* 3				OFF					
	5				ON					
BONUS POINTS 1ST / EVERY	* 20,000 pts. / 60,000 pts.				OFF					
	20,000 pts. only				ON					
GAME DIFFICULTY	* Rank A EASY					OFF				
	Rank B HARD					ON				
TEST MODE	* NORMAL GAME						OFF			
	TEST MODE						ON			
SCREEN INVERSION	* NORMAL							OFF		
	INVERSION							ON		
CONTINUED PLAY	WITHOUT									OFF
	* WITH									ON

HARNESS

Wire Color	Solder Side		Parts Side		Wire Color
Black	Ground	A	1	Ground	Black
Black	Ground	B	2	Ground	Black
Red	+5VDC	C	3	+5VDC	Red
Red	+5VDC	D	4	+5VDC	Red
	N/A	E	5	N/A	
Yellow	+12VDC	F	6	+12VDC	Yellow
	Post	H	7	Post	
Red	Coin Counter 2	J	8	Coin Counter 1	Violet
	Coin Lockout	K	9	Coin Lockout	
Black	Speaker (-)	L	10	Speaker (+)	Gray
	N/A	M	11	N/A	
Green	Video Green	N	12	Video Red	Red
White	Video Sync (Comp/Neg)	P	13	Video Blue	Blue
Pink	Service Switch	R	14	Video Ground	Black
Yellow	Tilt Switch	S	15	Test Switch	Blue
Orange	Coin 2	T	16	Coin 1	Tan
Gray	2P Start	U	17	1P Start	Brown
Green	2P Up	V	18	1P Up	Green
Blue	2P Down	W	19	1P Down	Blue
Violet	2P Left	X	20	1P Left	Violet
Yellow	2P Right	Y	21	1P Right	Yellow
Red	2P Fire	Z	22	1P Fire	Red
Orange	2P Bomb	a	23	1P Bomb	Orange
	N/A	b	24	N/A	
	N/A	c	25	N/A	
	N/A	d	26	N/A	
Black	Ground	e	27	Ground	Black
Black	Ground	f	28	Ground	Black


ARKANOID

NEW GAME PACKAGE CONTENTS

1 Main Printed Circuit Board (PCB)	1 Marquee
1 PCB Cage (FCC Required)	1 Control Panel Overlay
1 Set Legs, Bolts, & Spacers	1 Plex Control Cover
1 Connecting Wire Harness	1 Set Side Graphics
1 Control Assy.	1 Set Play Instructions & Function Labels
4 Player Button Assemblies	1 Service and Installation Manual

Note: Replacement accessories available through your exclusive **Romstar** distributor.

POWER REQUIREMENTS		MONITOR REQUIREMENTS
+5 VDC +12 VDC	7 amp minimum 1 amp minimum	Vertical Mount Raster Scan Negative Composite Sync



TM

© 1988 Pioneer Inc.
All Rights Reserved.
Licensed From
Palo Alto Corp.



CATCH CAPSULES AND REINFORCE THE VAUS!!



SLOW

SLOWS DOWN THE
ENERGY BALL.



LASER

ENABLES THE VAUS TO
FIRE LASER BEAMS.



CATCH

CATCHES THE ENERGY
BALL AND SHOOTS IT
WHEN YOU WANT TO.



BREAK

ALLOWS PLAYER
TO MOVE TO
NEXT PLAYFIELD.



EXPAND

EXPANDS THE VAUS.




PLAYER

GAINS AN ADDITIONAL
VAUS.



DISRUPT

SPLITS THE ENERGY
BALL INTO THREE
PARTICLES.



Time to Apply Power:

1. Look ~~and~~ smell for smoke. (TURN OFF IMMEDIATELY IF ANY IS NOTICED)
2. Listen for game sounds.

If after one minute you have not heard any sounds:

- A) Check for proper dip switch settings.
- B) Adjust volume control and check speaker connections.
- C) Check the +12V power supply to the logic board.


NOTE: If you do get sounds, but they are a little fuzzy, switch the wires around on the speaker.

3. How is the monitor image?

A) Is the picture in sync?

If your picture has the top and bottom halves of the screen reversed and it will not stop rolling, change your sync polarity on the monitor. (Positive to negative).

If your monitor does not have dual polarity positions for sync, then you will need to reverse the sync yourself by installing a simple one I.C. circuit between the logic board and the monitor. (The following illustration shows a hookup for both **composite** and **separate** syncs.




B) Now how's your picture?

- It centered?
- Is it too bright or dim?
- Is it in focus?



Check your monitor manual for these adjustments. If your screen looks "off", then your **new game** transformation may have been in vain. So let's take the time to make the monitor look great.

C) Is the picture upside-down?

Dip switch 7 should solve your problems.



CONTROL PANEL LAYOUT



TO REMOVE KNOB & SHAFT ASSEMBLY - REMOVE NUT, SPROCKET, & E-CLIP FROM MAIN SHAFT.

NOTE : USE CONTROL ASSY. AS A TEMPLATE FOR MOUNTING HOLES ON CONTROL PANEL.